

Keeping you
snug wherever
you call home...

How to Cut **THERMAFLEECE**



**therma
fleece**[®]
British wool insulation

TEARING THERMAFLEECE SHEEPS WOOL INSULATION TO SIZE

Tools Required: None / Gloves if preferred

Tearing is a simple and safe way to get the length of insulation required and is easy to just pull apart. Any uneven edges can easily be tucked under to provide a neat edge when installed.



CUTTING TO AN ACCURATE LENGTH USING THE 'ROLL & CUT' METHOD

Tools required:

Sharp Scalloped Edged Knife / Insulation Saw • Tape Measure • Gloves if preferred
• Hard Back Board for cutting onto •

Roll the insulation as tightly as you can along the width. Measure where you need to cut to give the length you require. With the scalloped edged knife or insulation saw, easily cut through. This results in a nice, neat edge, an alternative to tearing.



CUTTING TO AN ACCURATE WIDTH USING THE 'ROLL & CUT' METHOD

Tools required:

Sharp, Scalloped Edged Knife / Insulation Saw • Tape Measure • Gloves if preferred
• Hard Back Board for cutting onto

Keep the insulation rolled and do not unwind. Measure the required width that you need then begin to cut through the whole roll. Any offcuts are ideal to fill those hard to access spaces



YOUR NOTES

This information is given in good faith as a general guide to users and specifiers of Thermafleece. This information is not a substitute for any design that may be necessary to determine suitability of the products for your end-use. Since we have no influence over project or site specific issues, Eden Renewable Innovations Ltd makes no warranties or accepts no liability in relation to the use of this information.